



Wind speed effects on droplet size distribution

Ásta Hannesdóttir & Ebba Dellwik

Background

- Wind turbine blade erosion caused by rain
- Rain + wind + high tip speed = power washer



photo: armourededge.com




photo: powerfulgarden.com

Background

- A real wind turbine operating at high wind speed and in rain
- A video from Windmill Tech LinkedIn page ->
- Typical maximum tip speed: 70–100 m/s
- Typical terminal velocity of droplets: 0.5–7 m/s
- Impact velocity mostly determined by the tip speed



Erosion damage modelling

- We normally need to estimate the number of impacts or the amount of impinged water on the blade
- Not directly measurable
- Rain rates are estimated with rain gauges (worldwide)
- Converted into liquid water content in the air
- The size and fall-velocity estimated with the theoretical drop-size distribution (DSD) from rain rate data

The Best distribution

- The size distribution of raindrops
- By A. C. BEST, 1950

$$1 - F = \exp \left[- (x/a)^n \right]$$

$$a = A I^p$$

- Need for an update?
- Several studies point to a potential wind speed dependency in DSD
- High wind speed can enhance droplet breakup
- Higher wind speeds expected to shift the distribution toward smaller droplet sizes


Hypothesis

The Best DSD can be updated with a wind speed dependent variable



Risø meteorological mast



- 122 m tall tower with cup anemometers and wind vanes
- An OTT Parsivel laser-optical disdrometer at the top of the mast
- Rimco tipping bucket rain gauge
- From June 2019 – May 2023




Droplet size-velocity histograms

Theoretical curve for terminal fall speed vs. drop diameter, Atlas et al. 1973


$$V = 965 - 1030 e^{-6D}$$





WS dependent Droplet size-velocity histograms



WS dependent Droplet size-velocity histograms



Marginal drop size distributions



Conclusions

- We can neither reject or confirm our hypothesis
- We observe a shift from the theoretical curve for terminal fall speed
- At and above 8 m/s the disdrometer doesn't measure accurately, the spread is higher, and more errors occur
- As it is important for wind turbine blade erosion modeling to know the DSD at high wind speeds, other instruments should be used for these measurements
- The Best DSD needs an update and the wind speed dependence with new reliable DSD measurements in different wind and climate conditions



Thank you.

 @ProjectAire  @Aire Project



Funded by
the European Union

Funded by the European Union. Views and opinions expressed are however those of the author(s) only and do not necessarily reflect those of the European Union. Neither the European Union nor the granting authority can be held responsible for them.

